

CS6530D Digital Dissolved Ozone Sensor



Electrode characteristics:

Potentiostatic principle electrode is used to measure dissolved ozone in water. The potentiostatic measurement method is to maintain a stable potential at the electrode measuring end, and different measured components produce different current intensities under this potential. It consists of two platinum electrodes and a reference electrode to form a micro current measurement system. The dissolved ozone in the water sample flowing through the measuring electrode will be consumed. Therefore, the water sample must be kept flowing continuously through the measuring electrode during measurement.

The constant voltage measurement method uses a secondary instrument to continuously and dynamically control the potential between the measuring electrodes, eliminating the inherent resistance and oxidation-reduction potential of the measured water sample, so that the electrode can measure the current signal and the measured water sample concentration. A good linear relationship is formed between them, with a very stable zero point performance, ensuring accurate and reliable measurement.

The potentiostatic electrode has a simple structure and a glass appearance. The front end of the online dissolved ozone electrode is a glass bulb, which is easy to clean and replace. When measuring, it is necessary to ensure that the water flow rate through the dissolved ozone measuring electrode is stable.

This product is a digital sensor that integrates electronic circuits and microprocessors inside the sensor, referred to as digital electrode.

Potentiostatic digital dissolved ozone electrode sensor (RS-485) Features

1. Power supply and output isolation design to ensure electrical safety
2. Built-in protection circuit for power supply and communication chip, strong anti-interference ability
3. With comprehensive protection circuit design, it can work reliably without additional isolation equipment
4. The circuit is built inside the electrode, which has good environmental tolerance and easier installation and operation
5. RS-485 transmission interface, MODBUS RTU communication protocol, two-way communication, can receive remote commands
6. The communication protocol is simple and practical and extremely convenient to use
7. Output more electrode diagnostic information, more intelligent
8. The internal integrated memory can still memorize the stored calibration and setting information after power off
9. POM shell, strong corrosion resistance, PG13.5 thread, easy to install.

Application:

Drinking water: ensuring reliable disinfection

Food: to ensure food safety, sanitary bag and bottle methods

Public works: detection of residual chlorine

Pool water: efficient disinfectant

No instrument is required, 485 signal transmission, no interference on site, easy to integrate into various systems, and effectively reduce related use costs.

The electrodes can be calibrated in the office or laboratory, and replaced directly on site, with on-site calibration, which greatly facilitates later maintenance

Calibration information record is stored in electrode memory.

Model NO.	CS6530D
Power/Signal Output	9~36VDC/RS485 MODBUS RTU/4~20mA(Optional)
Measure material	Double platinum ring/3 electrodes
Housing material	Glass+POM
Waterproof grade	IP68
Measurement range	0-20mg/L
Accuracy	±1%F.S
Pressure range	≤0.3Mpa
Temperature compensation	NTC10K
Temperature range	0-80℃
Calibration	Water sample, chlorine-free water and standard liquid
Connection methods	4 core cable
Cable length	Standard 10m cable or extended to 100m
Installation thread	PG13.5
Application	Tap water, pool water, etc